


**AQUA<sup>®</sup>**  
**FORTE**

PROFESSIONAL POND PRODUCTS

## Floating fountain set



AQUAFORTE IS A TRADEMARK OF SIBO BV, HOLLAND  
[www.aqua-forte.com](http://www.aqua-forte.com)

# Floating fountain set

Read these instructions carefully before starting to install this equipment.

EN

## Operation


This pump can transport clean water. The pump will be used for the floating fountain. This pump can only be used in water.

## Safety

1. **Warning** - Due to the risk of injury, this product is not suitable for use by children or persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience or knowledge, unless they are supervised or instructed on the use of the device by a person responsible for their safety.
2. **Warning** - Risk of electric shock. If in doubt as to whether you have sufficient knowledge and experience, this device must always be connected by a certified electrician, according to the locally applicable standards and laws, with a properly earthed connection protected by a residual-current device.
3. **Warning** - To reduce the risk of electric shock, a damaged cable should be replaced immediately.
4. **Warning** - To reduce the risk of electric shock, the use of an extension lead is not recommended. Connect the device to an easily accessible mains outlet.
5. Do not bury the connection lead. Never share connections and/or connection leads with lawn mowers, hedge trimmers or other equipment.
6. Keep children away from this device and the electrical lead.
7. During and after commissioning, the unit is operating and filled with water. Therefore, to reduce the risk of electric shock, be careful during repairs and/or service work. If you lack the necessary knowledge and experience, repair and/or service activities should be performed by authorized/accredited technicians.
8. The device must not be switched on if it has been damaged during or as a result of transport, a fall, a production defect or other cause.
9. Always connect the device to an undamaged, earthed mains outlet with hinged cover.
10. Always remove the plug from the outlet when the device is not in use and/or during cleaning and maintenance activities. The plug must be removed from the mains outlet by pulling on the plug itself. Never pull on the lead to remove the plug from the outlet.
11. To reduce the risk of electric shock, the plug must not be inserted into or removed from the mains outlet with wet hands and/or while you are standing in the water.
12. The device should never be immersed, in whole or in part, in water or any other liquid.
13. The connection lead of the appliance may not be shortened and/or connected directly without a plug. If the lead becomes damaged, the entire device must be submitted to authorized/accredited technicians. Devices with cut-off/shortened cables are excluded from warranty coverage.
14. Use of the equipment for any purpose other than that for which it was designed or developed is not permitted. Use of the equipment for a purpose other than that for which it was developed by the manufacturer may lead to unsafe situations.
15. If there is a seasonal risk of freezing of the device, or parts thereof, appropriate measures must be taken to prevent freezing damage. Damage caused by freezing is always excluded from warranty coverage.
16. This device may only be used in accordance with the guidelines described in this manual. You must also

- adhere to the instructions provided on the device.  
17. Never carry or pull the pump by the cable.


### Installation



1. Plug the mains plug of the unit into an earthed socket with a protective cover. Never put the plug down in wet grass or on wet ground.
2. Remove the pump from your pond during frosty periods and clean it under running water (do not use high-pressure spraying pistol or corrosive detergents). Store the pump free from frost in a tank filled with water. (NEVER let the plug become wet!)

### Dismantling/Reassembly

Always unplug the power cable from the mains power supply before you dismantle the pump for maintenance. Never take the pump out of the water by pulling the power cable, this can cause damage to the power cable.



Remove pre-filter (1) and filter foam (2). Rotate disc (3) anti-clockwise and remove it. Remove rotor (4) and the ceramic shaft (5). Be careful not to damage these parts (ceramic shaft can break!).

The motor (6) is sealed and cannot be dismantled any further! Please contact a trained technician if you doubt the cable connection. You can reassemble the parts in reversed order.

#### Technical data

Mains voltage	220-240 V/50 Hz
Power consumption	60W
Flow in l/min	50
Cable length	10 m

#### Guarantee conditions

You have made an excellent choice in purchasing this product. The unit has been carefully assembled in compliance with all safety instructions. To ensure the highest possible quality of the product, the supplier has made use of high quality materials, and provides a 2-year guarantee from the date of purchase for material and production faults. Please be aware that the supplier cannot accept any claims under the guarantee that arise as a result of errors in the installation or operation, incorrect handling, non-compliance with safety regulations, inadequate maintenance, damage caused by lime scale, damage of any kind and the carrying out of any technical modifications of any kind. Guarantee claims can only be dealt with if the complete product is returned postage-paid and is accompanied by a valid proof of purchase. In case of a claim under the guarantee, the supplier reserves the right to either repair or completely replace your unit. Consequential damage is excluded from this guarantee, and the supplier will also provide no guarantee for parts subject to wear, for example, the rotor and ceramic axle.